



APARAT	R323-25 D-02 / 20A-9G	P312-B10/0.03-AC	P312-B10/0.03-AC	P312-B10/0.03-AC	P312-B10/0.03-AC	P312-B10/0.03-A	P312-B10/0.03-A	P312-B10/0.03-AC	P312-B10/0.03-AC	P312-B10/0.03-AC
OZNAČENIE OBWODU		TBS-1/1	TBS-1/2	TBS-1/3	TBS-1/4	TBS-1/5	TBS-1/6	TBS-1/7	TBS-1/8	TBS-1/9
MOC OBWODU	P=10.00 kW Ps=6.00 kW	1.40 kW	2.00 kW	1.00 kW	2.00 kW	1.00 kW	1.00 kW	1.20 kW	0.40 kW	REZERWA
TYP PRZEWODU		YDY-2x0.3x2.5mm²	YDY-2x0.3x2.5mm²	YDY-2x0.3x2.5mm²	YDY-2x0.3x2.5mm²	YDY-2x0.3x2.5mm²	YDY-2x0.3x2.5mm²	YDY-2x0.3x2.5mm²	YDY-2x0.3x2.5mm²	
ODBIORNIK	ZABEZPIECZENIE ZWARCOWE TABLICZ SIŁOWEJ TS-1	—⊞ 1 SZT	—⊞ 1 SZT	—⊞ 1 SZT	—⊞ 6 SZT	—⊞ 2 SZT	—⊞ 2 SZT	—⊞ 3 SZT	—⊞ 1 SZT	

TABLICA BEZPIECZNIKOWA TBS-1  
- SCHEMAT ODPIŁYWOŃ  
rys nr E10-atk 4